

Typical Cabinet Construction

(Other options available, if needed)

Boring for adjustable shelves, drawer slides and mounting plates, if desired

1/4" back with dado'd sides & bottom or 3/4" back captured on all sides

Pilot holes for screws; unless its a finished end (Dowel construction coming soon)

Top & Bottom are captured between sides

Available with no toe kick or integrated toe kick

35mm hinge boring & 8mm dowel hole

